




User's manual



Mirrorball Set with Motor

Table of content

1.	Safety instructions.....	3
2.	Installation.....	4
2.1.	Installation of the colour wheel.....	4
2.2.	Connection with the mains	4
3.	Opetration	4
4.	Cleaning and maintenance	4
5.	Technical Data	5

1. Safety instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature. Avoid exposing it to direct rays of the sun or near a heating appliance.

Not put it in a temperature below 41°F /5°C, or exceeding 95°F /35°C.

Keep away from humidity, water and dust

Do not place the set in a location with high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

If out of work, contact sales agency immediately

Any troubles arose, remove the power plug soon, and contact with an engineer for repairing, do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable

Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the player for an extended period of time be sure to disconnect the plug from the receptacle.

2. Installation

2.1. Installation of the colour wheel

Step 1: Fix the Color-wheel-motor to the lamp housing.

Step 2: Remove the foil of the Color-wheel.

Step 3: Screw the Color-wheel onto the motor.

2.2. Connection with the mains



The electric connection must only be carried out by a qualified electrician!

In order to connect the device to the mains, you have to install a power-plug.

The occupation of the connection-cables is as follows:

Cable	Pin	International
Brown	Live	L
Blue	Neutral	N
Yellow/Green	Earth	

The earth has to be connected!

Connect the device to the mains with the power-plug.

3. Opetration

After you connect the device to the mains, it starts running.

4. Cleaning and maintenance

We recommend a frequent cleaning of the device. Please use a soft lint-free and moistened cloth.

Never use alcohol or solvents!

There are no servicable parts inside the device. Maintenance and service operations are only to be carried out by authorized dealers.

Should you need any spare parts, please use genuine parts.

If the power supply cable of this device becomes damaged, it has to be replaced by authorized dealers only in order to avoid hazards.

Should you have further questions, please contact your dealer.

5. Technical Data

Power supply:	230 V AC, 50 Hz ~
Power consumption:	4 W
Rotation speed:	ca. 4 RPM
Color s:	red, green, yellow, blue
Diameter:	23 cm
Weight:	0.1 kg

Importeur:

B & K Braun GmbH

Industriestraße 1

D-76307 Karlsbad

www.bkbraun.com

info@bkbraun.com

